

Fitting instructions

Door bottom seal

LAS3007 si



Length:

Contents include

Decorative cover strip Pre-slotted holes Silicone rubber gaskets Aluminium carrier Bag of screws Fitting instruction

Tools required

Tape measure
Saw (power or hand)
Screw driver
Drill (power or hand)
2.5mm Drill bit
Knife
Pencil or marker

For further information about our products please visit our website

www.lorientgroup.com

t: +61 (02) 9905 0868

f: +61 (02) 9905 0883

e: admin@lorientau.com.au

Instructions

It is not necessary to remove the door from the hinges and no painting is required after installation. This seal may be fixed to either side of the door bottom.

1. Remove the seal from the packaging and with the door closed, measure the width of the door bottom from the side of the door to which the seal is to be fixed.

Note: If the carrier is to be screw fixed to the stop side of the door then the face of the aluminium carrier will have to be checked out by the width of the door stop (at each end) to ensure that it does not bind and stop the door from closing and latching.

- Remove the decorative cover strip and pull back silicone gaskets from the aluminium carrier.
- **3.** Cut the aluminium carrier to the length required.

Important

Ensure that the installation of this product does not impede the opening or closing of the door. It is recommended to check the adjustment of the door seal periodically to ensure the door assembly to which it is fitted, closes and latches properly.

Please note: Recommendations as to methods, use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers.

Lorient reserves the right to make alterations or delete installation detail without prior notice.

- **4.** Cut the decorative cover strip to the length required.
- **5.** Refit the silicone gaskets to the aluminium carrier and cut to length.
- 6. Apply the seal to the door bottom, allowing a minimum gap of 13mm between the door bottom and the door sill. Mark out the slotted hole locations with a pencil ensuring the silicone gasket blades lightly touch the floor.
- 7. Drill pilot holes with a 2.5mm drill bit.
- 8. With the screws provided fix the LAS3007 si seal to the bottom of the door leaf. (For uneven gaps, slight adjustment can be made via the slotted holes prior to tightening the fixing screws).
- **9.** Refit the decorative cover strip.



We recommend LAS3007 si door bottom seal be used together with a LAS4015 threshold plate.

Other Lorient products:

Acoustic, smoke & fire seals
Fire resistant glazing systems
Fire resistant door hardware
Air transfer grilles/ dampers



Lorient Pty Ltd Unit 30, 9 Powells Road Brookvale 2100 New South Wales Australia

+61 (02) 9905 0868 www.lorientgroup.com

All rights reservered. No part of this fitting guide may be reproduced, stored in a retrieval system, or transmitted in any means, electronic, mechanical, photocopying, recording or otherwise without the written permission of Lorient Polyproducts Limited.

© Lorient Polyproducts Ltd 2018