

Fitting instructions

Door bottom seal

LAS3002 si



Length:

Contents include

Aluminium carrier Pre-drilled holes Silicone "Push-fit" gasket Bag of screws Fitting instructions

Tools required

Saw (power or hand) Screw driver Drill (power or hand) Knife Pencil or Marker Router

For further information about our products please visit our website

www.lorientgroup.com

t: +61 (02) 9905 0868 f: +61 (02) 9905 0883 e: admin@lorientau.com.au

Instructions

- **1.** If installed, remove door from its hinges, lay door on its edge and firmly restrain.
- 2. Measure and mark out the seal position along the centre line of the door stile/ bottom. (Note that the finished groove should be 20mm wide).
- **3.** Fit a suitable cutter into the router, set guide and machine a 5mm deep groove along the edge/bottom of the door.
- **4.** Clean dust and chips from the groove and check depth by applying seal.

Please note: Recommendations as to methods, use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers.

Lorient reserves the right to make alterations or delete installation detail without prior notice.

Measure the door height/ width and cut the seal to suit, using a sharp knife for the silicone

casket and a saw for the aluminum section.

Replace silicone gasket and screw fix the

7. Ends of the aluminium channel may be centre punched to prevent gasket movement.

aluminiumsection into the groove using the

screws supplied (fixing holes are pre-drilled).

Important

Ensure that the installation of this product does not impede the opening or closing of the door. It is recommended to check the adjustment of the door seal periodically to ensure the door assembly to which it is fitted, closes and latches properly.

We recommend the LAS3002 si be used together with a Lorient threshold plate.

Other Lorient products:

Acoustic, smoke & fire seals Fire resistant glazing systems Fire resistant door hardware Air transfer grilles/ dampers



Lorient Pty Ltd Unit 30, 9 Powells Road Brookvale 2100 New South Wales Australia

+61 (02) 9905 0868 www.lorientgroup.com

All rights reservered. No part of this fitting guide may be reproduced, stored in a retrieval system, or transmitted in any means, electronic, mechanical, photocopying, recording or otherwise without the written permission of Lorient Polyproducts Limited. © Lorient Polyproducts Ltd 2018